

Adjustable Banner Frame


Banner Frame Includes:

- A. 2 Vertical Poles
- B. 2 Telescoping Crossbars
- C. 2 Ground Inserts
- D. 7 Zip Ties
- E. 2 Wing Nuts
- F. Metal Washers
- G. 4 Clamps
- H. 4 Bungee Cords

GREAT AMERICAN'S

ADJUSTABLE BANNER FRAME:

- ★ Portable frame can be adjusted to fit banners up to 10' long.
- ★ Easy to assemble, no tools needed!
- ★ Fits banners up to 10' long.




Frame Assembly:

1. Open the clips on the 2 vertical poles (A) and extend them to the desired height. Push the clips back down to secure it in place.
2. Connect the two telescoping crossbars (B) by inserting the tapered ends into each other. Adjust to the desired width and twist to tighten into place.
3. Insert the top of the vertical poles (A) into the holes each end of the crossbar (B). Secure the two together with a washer (F) and wing nut (E) on each end and hand tighten.
4. Slide each end post of the assembled frame over an installed ground stake.




Ground Stake Installation:

1. Determine where you want to display your banner and lay down the frame to mark where to install the ground inserts (C).
2. Twist the red cap on the top to release the red handles on either side of a ground insert (C). Pull down the handles, place the insert in your desired location and twist and rotate to secure it in the ground. Repeat at the other end of the banner frame.



Hanging your Banner:

1. Insert the bottom of each vertical pole of the frame into the installed ground inserts (C) and tighten the red caps to secure the frame.
2. Loop the provided zip ties (D), through the holes on your banner and wrap it around the banner frame. Straighten your banner and pull it taut before fully tightening the zip ties.



Note:
For smaller banners, you can use the provided bungee cords or clamps as an alternate way to secure your banner.

