6ft. Picnic Table Assembly

Maximum Weight Capacity: Table = 300lbs. / Bench Seats = 500lbs.

EXPLODED VIEW

PARTS LIST

|							
A	Table Top (x1)	**D**	Bench (x2)	**G**	Bolts (x12)
B	Table Supports (x4, attached)	**E**	Bench Support Legs (attached x4)	**H**	Nuts (x12)
C	Table Support Arms (attached)	**F**	Table Support Extensions (x4)	**I**	Table Base (x2)

Maximum Weight Capacity: Table = 300lbs. / Bench Seats = 500lbs.

TABLE ASSEMBLY

STEP 1 Unpack the contents of the package and lay the parts flat on the cardboard for assembly to help avoid damage to the table.

Step 2 Place the table top (A) face down and extend the table support legs (B) and lock in place using table support arms (C) and locking pins.

Ensure locking pins are secured in place.

Step 3 Insert table support extensions (F) into the table base and secure using 4 bolts (G) and 4 nuts (H). Repeat this process for the second table base (I).

Finger Release Tabs (Outward)

Step 4 Insert assembled table base (parts F, I) into table supports (B) and secure using the finger release tabs on the table support extensions. Repeat for second table base (F, I).

Finger Release Tab

Finger Release Tab

Step 5 Invert the table so that it is right-side up. Extend the bench leg (E) on the bench seat (D) and insert into the table base (I). Secure the bench support leg (E) with 1 bolt (G) and 1 nut (H) to the table base. Repeat this process with the second bench.

ASSEMBLED TABLE

## FOLDING ASSEMBLED TABLE FOR STORAGE

STEP 1 To fold the table for storage, release the finger release tabs located on the table support extensions (F) so that the table top is at the same level as the bench seat (D).

Step 2 Turn the table upside down and release the locking pins. Slide the lock ring up and out of the way. Lay the table legs flat against the underside of the table. Repeat for the second side.

STEP 3 Secure the legs in place using the velcro tabs located on the underside of the table (attached).

ASSEMBLED TABLE FOLDED FOR STORAGE